

Honeywell VISTA-15P/20P User Guide (rev. 20120913)

To ARM the system and go AWAY

1. Secure all doors and windows.
2. Enter your 4-digit USER code and press [2].
3. Red ARMED message will display.

To ARM the system and STAY in building

1. Secure all doors and windows.
2. Enter your 4-digit USER code and press [3].
3. Red ARMED message will display.
4. Motion detectors will be bypassed.

To ARM the system in INSTANT mode.

1. Secure all doors and windows.
2. Enter your 4-digit USER code and press [7].
3. Entry delay will be turned off and red ARMED be displayed.

To DISARM the system

1. Enter building through a delay door.
 - Control station will beep to remind you to disarm the system.
2. Enter your 4-digit code.
 - Red ARMED light should go off.

To CHANGE a MASTER code

1. Enter your 4-digit MASTER code.
2. Press [8] then 02.
 - a. User 02 is reserved for System Master.
3. Enter in new 4-digit MASTER code TWICE (ex. 1234 8 02 5678 5678)
 1. The keypad beeps once to confirm that new user was added.

To CHANGE a USER code

2. Enter your 4-digit MASTER code.
3. Press [8] + user number you wish to add.
 - a. Start with User 03 to 33
4. Enter in desired user's security code. (ex. 1234 8 03 1111)
5. The keypad beeps once to confirm that new user was added.

To DELETE a USER code

1. Enter your 4-digit MASTER code
2. Press 8 + user number you wish to delete.
3. Press the pound [#] sign then [0] (ex. 1234 8 03 # 0)

[DO NOT delete the MASTER code USER 02]

To activate EMERGENCY alarm

1. Press emergency button corresponding to the emergency type for 2 seconds.

To turn the DOOR CHIME ON/OFF

1. Enter your 4-digit USER code.
2. Press 9.
3. Repeat to turn off.

To BYPASS a ZONE

1. Enter your 4-digit USER code.
2. Press [6] + zone numbers. (ex. 1234 6 02 or 11 – MUST BE TWO DIGITS).
3. Keypad will display ZONE BYPASSED when armed.

To SILENCE and view trouble condition

1. The word CHECK will be displayed on the keypad
2. Too silence, press any key.
3. Trouble signals are below:
 - COMM. FAILURE (or FC)
 - a. Indicates that a failure has occurred in the telephone communication portion of your system. (CALL FOR SERVICE)
 - SYSTEM LO BAT (or BAT with no zone No.)
 - a. Indicates that a low system battery condition exists. Display accompanied by "beeping" at the keypad.
 - LO BAT + zone
 - a. Indicates that there is a low batt condition in the wireless transmitter number displayed (00 is RF keypad)
 - Rcvr Jam (or CHECK 90)
 - a. Wireless part of the system is experiencing RF interference. (CALL FOR SERVICE)
 - ALARM 1xx, FAULT 1xx, CHECK 1xx (or 91)
 - a. Indicates a comm. Problem between the control and a connected device. (CALL FOR SERVICE)
 - MODEM COMM (or CC)
 - a. Indicates that the control is on-line with Central Station remote computer.
 - BELL FAILURE (or CHECK 70)
 - a. Indicates that the wiring connection to the external sounder is at fault. (CALL FOR SERVICE)
 - AC LOSS (or NO AC)
 - a. Power failure
 - Busy-Standby (or dl)
 - a. CALL FOR SERVICE
 - OPEN CIRCUIT (or OC)
 - a. The keypad is not receiving signals from the control (CALL FOR SERVICE)
 - TELCO FAULT (or CHECK 94)
 - a. The telephone line has a problem

To CHANGE the system TIME/DATE

1. Enter your 4-digit MASTER code
2. Press [#] then [6] then [3]
3. Press [*] when the time/date is displayed. A cursor will appear in the first digit of the hour (To move ahead, press [*], backwards [#])
4. Enter the 2 Digit hours setting, 2 digit minute setting. Press [1] for PM or [2] for AM. Enter the last two digits of the current year. Enter the 2-digit month, Enter the 2-digit day.
5. To exit, press [*] when the cursor is at the last digit or, or wait 30 seconds.

To clear MEMORY LIGHT

Contact us if you are unaware of the recent alarm activation causing the MEMORY:

1. After disarming, enter USER code again.
2. Press OFF [1] key again.